

Product Improvements

Document	New Part – MicroPurge [®] MP25T Flow Cell System	Date: 03/06/2023
Model	MP25T	Page: 1 of 2
Serial Numbers	ALL	
Description	MP25T pH/ORP Sensor Guard	
Part Number	42193	

Summary:

The MP25T system use a combination pH/ORP sensor with the glass pH sensor bulb located at the tip of the sensor. As with any pH sensor, handling and servicing of the sensor could result in accidental damage if the glass bulb is impacted or the sensor or probe are dropped. Breakage of the glass bulb is not covered under the QED warranty.

QED has designed an individual sensor guard for the pH/ORP sensor to reduce the risk of pH bulb damage and improve field ruggedness. This 3D printed guard slips over the end of the sensor and encloses it to protect from accidental damage while still allowing exchange of water around the sensor to assure accurate measurements.

New Part:

The new pH/ORP sensor guard PN# 42193 for the MicroPurge[®] MP25T Flow Cell System is designed to protect the glass pH bulb on the end of the sensor from accidental breakage during use. This 3D printed part slips neatly over the end of the sensor, enclosing it for protection while still allowing for exchange of water around the sensor for accurate measurements. The guard easily slides off to allow for cleaning of the pH bulb and ORP electrode during routine maintenance.

MP25T pH/ORP Sensor
Guard – PN 42193



Product Improvements

Document	New Part – MT25T QEC-2022-224 & QEC-2022-261	Date: 03/06/2023
Model	MT25T	Page: 2 of 2
Serial Numbers	ALL	
Description	MP25T pH/ORP Sensor Guard	
Part Number	42193	

Additional Support:

To purchase the 42193 pH Sensor Guard or if you have any additional questions please contact our Technical support team at service@qedenv.com or call us at 800-624-2026 or +1-734-995-2547 and select option 2 for Service.